

## インド Bharat Stage V 規制：OEM やエンドユーザーに提供する情報と指示について

標記の件、インド Bharat Stage V 規制（インド BS V 規制）よりエンジンメーカーが OEM に提供する情報と指示、併せて、エンジンメーカーからの情報を基に OEM がエンドユーザーに提供する情報と指示に関する規制が導入されました。この規制に適合するため、クボタでは下記の対応を実施致します。

### 記

#### < 1 > 規制の概要

AIS-137 (Part 7), A2 規制に従い、インド BS V 規制の開始又は BS V 認証を有するエンジンの生産以降、<2>規制の内容の通り、情報提供及び指示をすることが求められる。

#### < 2 > 規制の内容

以下の a 及び b のような情報提供を求められる。

##### a. クボタ⇒OEM

- ・農機/建機/コンバインハーベスタにエンジンを正しく搭載するために必要なあらゆる関連情報及び説明  
(エンジンの搭載または使用にかかわる特別な条件または制限の説明を含む)
- ・BS V 型式認証過程で測定した二酸化炭素の値 (試験条件を含む)

##### b. OEM⇒エンドユーザー

- ・排ガス性能を維持するため、エンジンを正しく運転するのに必要なあらゆる指示書
- ・BS V 型式認証過程で測定した二酸化炭素の値 (試験条件を含む)

#### < 3 > 規制の対象と適用時期

2025年1月1日：インドで稼働する BS V(建機)ラベルを有する、全ての CI エンジン

2026年4月1日：インドで稼働する BS V(農機、コンバインハーベスタ)ラベルを有する、全ての CI エンジン

#### < 4 > 情報の提供方法

以下の方法にて情報を提供致します。

##### a. クボタ⇒OEM

- ・KEP (Kubota Engine Park, <https://ba.engine.kubota.com/>) にて公開する。

##### b. OEM⇒エンドユーザー

- ・クボタ発行の取扱説明書に内容追加して対応する。  
(適用時期はモデルによって前後する。)

#### < 5 > その他の特記事項

特記 1) 文面については、英語のみ対応予定です。現時点で英語以外の対応予定はございません。

以上

## **Additional information and instructions by Bharat Stage V**

The information and instructions to be provided to end-users were added by Regulation AIS-137 (Part 7), A2, Bharat Stage(BS) V(CEV/TREM).

### **Engine operation and maintenance**

You must comply with the following things when you operate an engine.

- The engine, including the emissions control system, shall be operated, used and maintained in accordance with the instructions provided to the end-users in order to maintain the emissions performance of the engine within the requirements applicable to the engine's category.
- No deliberate tampering with or misuse of the engine emissions control system should take place; in particular with regard to deactivating or not maintaining an exhaust gas recirculation (EGR) or a reagent dosing system.
- When a warning lamp lights up, a trouble is happening to the engine and it may cause trouble to the emission control system. It is essential to take prompt action to rectify any incorrect operation, use or maintenance of the emissions control system in accordance with the rectification measures indicated in the 'TROUBLESHOOTING', or where applicable, 'OPERATOR WARNING AND INDUCEMENT' in the OPERATOR'S MANUAL.
- The operator will be informed by the operator warning system when the emission control system does not function correctly.
- For agricultural tractor or construction equipment vehicle or combine harvester with an operator inducement system, ignoring the operator warning signals will lead to the activation of the operator inducement system, resulting in an effective disablement of agricultural tractor or construction equipment vehicle or combine harvester.
- Explanations of how the operator warning including the consequences, in terms of performance and fault logging, of ignoring the warning system signals and of not replenishing, where used, the reagent or rectifying the problem identified is mentioned in the OPERATOR'S MANUAL.
- Where the engine is to be operated on diesel or non-road gas-oil, a statement indicating that a fuel with sulphur content not greater than 10 mg/kg (20 mg/kg at point of final distribution) cetane number not less than 51 and an FAME content not greater than 7.0 per cent v/v shall be used.

- Where applicable, it is essential to use and refill reagent in accordance with the specifications as we instruct in the OPERATOR'S MANUAL.

### **Carbon dioxide (CO<sub>2</sub>) emissions**

This CO<sub>2</sub> emission value results from testing over a fixed test cycle under laboratory conditions of an (a parent) engine representative of the engine type (engine family) and shall not imply or express any guarantee of the performance of a particular engine once installed in a agricultural tractor or construction equipment vehicle or combine harvester.

---

FAME: Fatty acid methyl ester

v/v : Volume per volume

**The list of BS V CO<sub>2</sub> emission value results of each engine family**

Please note that this CO<sub>2</sub> emission value results from testing over a fixed test cycle under laboratory conditions of an (a parent) engine representative of the engine type (engine family) and shall not imply or express any guarantee of the performance of a particular engine.

Ignition	Power category	BS V engine family name	Test cycle	CO <sub>2</sub> emissions [g/kWh]
CI	0-19kW	RKBXL02.2ECB	NRSC	842.47
		RKBXL01.5BCB	NRSC	896.3
	37-56kW	RKBXL02.4E1D	NRTC	<u>818.3</u>
			NRSC	785.9
		RKBXL03.8C1D	NRTC	<u>787.5</u>
			NRSC	751.0
		<u>RKBXL02.6E1D</u>	<u>NRTC</u>	<u>810.7</u>
			<u>NRSC</u>	<u>765.8</u>
		<u>RKBXL03.3E1D</u>	<u>NRTC</u>	<u>800.5</u>
			<u>NRSC</u>	<u>743.8</u>

---

NRTC : Non-Road Transient test Cycles

NRSC : Non-Road Steady-state test Cycles